

The unit gets warm when on

• It is completely normal for the front of the unit to feel slightly warm.

The lights won't dim up or down or flicker

- Are they compatible—see the guide on the first page?
- Is the total wattage higher than the minimum load?
- Ensure that when using low voltage lighting the transformer is dimmable

### The green-i locator is off or dim

- . This is only on when the lights are off
- The brightness of the locator can be changed by pushing and holding the down button when the



Voltage 230VAC +/- 10% Frequency 50Hz 0°C to 35°C Temperature

Power

see ratings on front page BS EN60669-2-1 & BS EN55015 Compliance

EU registered design no. 000638069-0003, 000638069-0004



C.P. Electronics Ltd

Unit 2 Abbey Manufacturing Estate Mount Pleasant, Wembley Middlesex. HA0 1RR

+ 44 (0) 20 8900 0671 + 44 (0) 20 8900 0674 Fax: www.cpelectronics.co.uk

enquiry@cpelectronics.co.uk

%WD277Issue 1



advancedswitchtechnology



Part no.

• Single gang dimmer

• Replaces a standard light switch or dimmer


- Security mode
- Night light mode\*
- Scene setting and soft on/off\*




GI1DT

GI1DC

\*only available using remote handset








This product should be installed in accordance with the current IEE wiring regulations.


If in doubt consult a qualified electrician.




Use the extender if there is less than 18mm free space.

REMEMBER—put the wires through the extender before connecting








Battery change Use only Lithium coin cell CR2025.



button not used

6 hours



### Overload protection

30%

An internal temperature sensor on the device ensures that if the unit is overloaded or the ambient temperature rating is exceeded then the no permanent damage is caused to the unit. When an excessive temperature is measured, the output will dim down until the correct temperature is restored. The green-i locator will flash to warn that this is happening.

### Adaptive dimming control

To enable the correct dimming level to be selected easily by the user, the off button is disabled for a short period of time during adjustments, enabling it to be used just for down control.

### Security mode

If your house is vacant and you want the lights to give the impression that someone is in, use the security mode. Shortly after it gets dark outside (15 minutes) the lights will turn on, and then turn off after a preset period of time. The dimming level for security mode will be the last level used or 50% whichever is greater.

## Soft on

To prevent the discomfort of bright lights turning on when you wake up, this mode senses the daylight level and if it is very dark will dim the lights up slowly for maximum user comfort.









turn lights on

turn lights off

dim down

set lights to preset scene number

To set scene levels:

- · adjust lights to desired level
- · store scene using this sequence:

dim up















## Soft on-how quickly the lights turn on

- Immediate
- 2 sec
- 7 sec
- depends on measured light level. If it is very dark, the lights will dim the lights up slowly for maximum user comfort.



- Immediate
- 2 sec
- 7 sec
- 10 sec

# wiring



1 way switching If the lights are controlled from one location only, wire as in the diagram.

Neutral ■ Black or Blue Live Red or Brown Yellow Green Earth Strapper • • • Yellow or Grey


## 2 way switching

Where lighting is switched from more than one location, this unit can be used with another single gang light switch. N.B. do not use with another dimmer switch.

Depending on the installation, wire using one of the diagrams below.

## 2 Way Switching—A

# 2 Way Switching—B







Short press—lights on

Long press—lights dim up



When lights on

Short press—lights off

Long press—lights dim down

## When lights off

Long press—change brightness of green-i locator





Remove front cover





Security mode activated. 4 hours time selected (see remote handset for details).



Security mode deactivated (can be overridden by remote handset).



Master reset. Flick switch on then off within 2 seconds to restore factory default settings.